



## Inrush current



## Dimensions



## Installation


**1**

**2**

Item Description	L1 (mm)
Essence Slim 600	≤470
Essence Slim 1200	≤1020
Essence Slim 1500	≤1320

**3a**

**3b**



**Warning**

- Only qualified electrician is allowed to do installation, maintenance and inspection for safety concern. It is dangerous for non-professional operators.
- Power should be cut off before installation, maintenance or inspection.
- Please install and use the product strictly according to the instruction.
- Do not disassemble or remold the product at will to avoid accident of electric shock or light falling.
- Working out of temperature range of -25 ~ +40°C will shorten the lifetime of the product.

